



ZX QUICK-START GUIDES

An overview of how to install the ZX Panel® cladding system

Soffit Installation



- Cut ZX-2P2 to size and fit ZX-213 J Mould Cap to edge of panel facing away from the house



ZX-2P2

ZX-2P2 Panel 2400 X
1200 X 2mm
- Powder Coated



ZX-213

ZX-213 J-Mould Cap x 5.4M -
Powder Coated

- Join ZX-2P2 panels with ZX-214 H-jointer



ZX-2P2

ZX-2P2 Panel 2400 X
1200 X 2mm
- Powder Coated



ZX-214

ZX-214 H-Jointer x 5.4M -
Powder Coated

- Fix to Soffit Bearer at 600 centres (or as required)
- Fix using ZX-24 screws



ZX-24

ZX-24 M12x25mm FH SQ
Tek Screws T410 Hardened
- 1000 per box